


MD39 Body Camera


Manual V1.1.5


Note: Please read the manual carefully before using.

Please abide by local laws and do not use this product for any illegal purpose. All consequences shall be borne by yourself.




Button and Indicator Lights introduction:


 -Power button: Press the button 2 seconds to power on or power off. After power-on, the red light turns on. 4 seconds later, the red light flashes twice and enters standby mode.

 -Record button: Click once to start/stop recording. Recording will be saved automatically when stopped.


When recording, the Red light flashes; when in standby mode, the Red light stays on.

 -Photo button: Click once to take one photo.

The red light flashes once when taking a photo.

 -Record button only sound: Click once to start/stop recording. Data will be saved automatically after stopping.

The blue light flashes during recording.

 -WIFI button: Click once to turn on/off WIFI;

Press and hold for 2 seconds to turn on/off the night vision light.

When the green light is on, WIFI is enabled; when the green light is off, WIFI is disabled.

R-Reset Button

Note:

- 1) Before using the device, insert a normal memory card (TF card) firstly.
- 2) The device memory card must be 8GB or above. Data can't be saved normally less than 8GB memory .
- 3) After the WIFI is turned on, the recording will be paused, and it can be operated within the APP.

Charging:

This device is equipped with a rechargeable lithium battery. When the battery is low, you can connect it to a charger for charging

Note:

- 1) Please use a 5V 1A charger;
- 2) The red and blue lights flash during charging, and stay on when fully charged.

One. Product operation:**1. Record with charging:**

When the device is powered off, connect it to the charger; it will enter charging mode. Press the record button once; the red light flashes to start recording.

Note: It is not possible to record while charging when the device is connected to a computer.

2. Reset:

In case of system error or malfunctioning, need to reset the device.

Method:

Press the reset button(R) to reset.

3. Time setting:

When the APP connects to the device, it will synchronize the correct time.

Two.WIFI Hot spot Connection:

1. APP Download : Scan the QR code below to install, or search for "Viidure" on Google Play or the App Store to download and install.






2. Turn on the WIFI: After the device is powered on, click the Wifi button once. When the green light is on, the WIFI is turned on.
3. Click to add the device: Select the device hotspot: DV-MD39-XXXX, and the initial password is: 12345678.

Note:

If you forget the device's WIFI password, you can restore the default password by following these steps:

- 1) Power on the device to standby mode, do not enable WIFI or turn off WIFI;

2) Press the  and  buttons once simultaneously to restore the default password.



Three. Product parameters:

Video format: AVI

Video coding: M-JPEG

Video resolution: 1920*1080

Video frame rate: 30fps

Battery capacity: about 1200mAh

Record time: about 8h

Charge voltage: DC-5V 1A

Storage support: 8GB-128GB

Transmission speed: USB 2.0

Interface type: Type-C

Storage temperature: - 10-40 °C

Working humidity: 15-85% RH9

Disclaimer

1. The usage of this device is subject to the relevant national laws and regulations, DO NOT use this product for any illegal activities.
2. DO NOT point the camera lens to the direct sun light or permanent damage may occur.
3. Keep away from fire. Never expose the device to any fire source.
4. DO NOT disassemble and modify. Doing so causes the risk of electric shock, burn injury and other health related hazard.
5. DO NOT let water, liquids, or foreign matter get inside the device. Extra precaution is advised where it is raining, snowing, near the ocean or other form of water. In case any of the symptoms are present, turn off the device immediately and contact us for further support.
6. DO NOT drop the device or permanent damage may occur.